

Sears Tele 310

Fabricant (si # de la marque) :		Pays de fabrication :	
Début de fabrication :	1979	Fin de fabrication :	0
Rareté :	Rare	Page du McKeown :	-
Type d'appareil :	Miniature		

Film

Type de film :	110	Nombre maxi de vues :	20
Format :	13 x 17 mm	Format :	
Format :		Format :	
Avancement :	Telescopique	Position :	-
Rembobinage :	Non	Position :	-

Exposition

Cellule :	Non	Position :	
Sensibilité :			

Obturbateur

Marque de l'obturateur :		Modèle de l'obturateur :	
Type d'obturateur :		Vitesses :	1/125

Objectif

Type d'objectif :		Montage de l'objectif :	Autre
Marque de l'objectif :		Modèle de l'objectif :	Anastigmat
Monture d'objectif :		Mode de map :	
Focale :	40 et 25 mm	Ouverture maxi :	5,6

Divers

Type de pile :	LR 6	Couleur du soufflet :	
Forme du soufflet :		Décentrement horizontal :	
Décentrement vertical :		Second viseur :	
Type de viseur :			

Le Sears Tele 310 est un bi-focale. Un curseur permet de déplacer un complément afin de transformer le 25 mm en 40 mm.

www.collection-appareils.fr

www.collection-appareils.fr

(1) Sears Tele 310 Electronic Flash Camera Outfit
 LENS, SHUTTER, FOCUS: See Chart below. Normal or telephoto lens. Fixed focus.
 EXPOSURE CONTROL, FLASH: Fixed for daylight or flash. Also accepts ASA 400 film. Built-in electronic strobe flash with ready light. Recycles in about 10 seconds.
 CONSTRUCTION: Black plastic body, brown vinyl trim. 6x2.25x1 in. Lens selection switch. Snap together slide-action body to cock shutter and advance film. Imported.
 ACCESS: Strap. 12-exp. color print film. 2 AA batt., instr.
 ORDERING INFORMATION: See Warranty below.
 3 HA 7825—Shipping weight 1 lb. \$34.50

(2) Sears 310 Electronic Flash Camera Outfit
 LENS, SHUTTER, FOCUS: See Chart below. Fixed focus.
 EXPOSURE CONTROL, FLASH: Fixed for daylight or flash. Built-in electronic strobe flash with ready-light. Recycles in about 10 seconds.
 CONSTR: Black plastic body, brown vinyl trim. 6x2.25x1 inch. Snap together slide-action body to cock shutter and advance film. Imported.
 ACCESS: Strap. 12-exp. color print film. 2 AA batt., instr.
 ORDERING INFORMATION: See Warranty below.
 3 HA 7803—Shipping weight 1 lb. \$29.50

(3) Sears Tele 110 Flip-flash Camera Outfit
 LENS, SHUTTER, FOCUS: See Chart below. Normal or telephoto lens. Fixed focus.
 EXPOSURE CONTROL: Fixed for daylight or flash. Uses flip-flash.
 CONSTRUCTION: Black plastic body, brown vinyl trim. 4.75x2.25x1.25 inches. Lens selection lever. Imported.
 ACCESS: Strap. 12-exp. color print film. Flip-flash, instr.
 ORDERING INFORMATION: See Warranty below.
 3 HA 7805—Shipping weight 1 lb. 6 oz. \$19.50

(4) Sears 110 Flip-flash Camera Outfit
 LENS, SHUTTER, FOCUS: See Chart below. Fixed focus.
 EXPOSURE CONTROL: Fixed for daylight or flash. Uses flip-flash.
 CONSTR: Black plastic, brown vinyl trim. 4.5x2.25x1 in. Imported.
 ACCESS: Strap. 12-exp. color print film. Flip-flash instr.
 ORDERING INFORMATION: See Warranty below.
 3 HA 7800—Shipping weight 1 1 oz. \$14.50

(5) Sears 10/10EF Camera Outfit
 LENS, SHUTTER, FOCUS: See Chart below. Wideview lens great for group shots. Fixed focus.
 EXPOSURE CONTROL, FLASH: Two aperture settings. Auto film speed setting for ASA 100 and 400 film. Pop-up flash. Recycles in 9 seconds.
 CONSTRUCT: Black plastic and metal. 4.5x2.5x1.5 inches. Imported.
 ACCESSORIES: Strap. 12-exp. color print film. 2 AA batt., instr.
 ORDERING INFORMATION: See Warranty below.
 3 HA 7809—Shipping weight 2 lbs. \$49.50

Sears 110 Pocket Cameras



110 Camera Cases



(6) 110 Camera Case
 For cameras smaller than 5 1/2x3x1 1/2 inches high. For camera alone . . . not accessories.
 CONSTRUCTION: Tan, leather-look vinyl with flap enclosure. Belt-loop for convenient carrying.
 ORDERING INFORMATION:
 3 HA 8309—Shipping weight 4 ounces \$2.99

(7) 110 Gadget Bag
 Accommodates 110 type cameras. Designed to hold camera, flash cubes, extenders, film and accessories.
 CONSTRUCTION: Dark brown leather-look vinyl with lining. Buckle-type shoulder strap with adjustable length. Nylon zipper. Brass-plated hardware. 6 1/2x2 3/4x4 1/2 in. high.
 ORDERING INFORMATION:
 C3 HA 8303—Shipping weight 1 pound \$7.99

FULL ONE-YEAR WARRANTY

If, within one year from the date of purchase, this camera fails to operate properly due to defect in material or workmanship, return it to the nearest Sears store in the United States, and Sears will repair it, free of charge. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Lens and Shutter Spec. Chart (1 thru 5, 8 thru 11)

Item	Lens			Shutter	
	Focal Length	Maximum Aperture	Minimum Focus	Type	Seconds
(1)	40 or 25mm	f5.6	5 ft.	Fixed	1/125
(2)	25mm	f5.6	5 ft.	Fixed	1/125
(3)	43 or 25mm	f11	5 ft.	Fixed	1/60
(4)	25mm	f11	5 ft.	Fixed	1/90 or 1/45
(5)	20.5mm	f4.0	3 ft.	Fixed	1/125
(8)	25mm	f11.9	4 ft.	Fixed	1/30, 1/100, 1/125, 1/175, 1/350
(9)	25mm	f8.0	4 ft.	Fixed	1/30, 1/100, 1/125, 1/175, 1/350
(10)	22 or 44mm	f9.5 or f11	5 ft.	Fixed	1/60, 1/125, 1/210
(11)	25mm	f11	5 ft.	Fixed	1/40, 1/100, 1/170


(8) Kodak Ektramax Camera Outfit
 LENS, SHUTTER, FOCUS: See Lens and Shutter Specification Chart below. left. 5-speed shutter. Zone focus.
 EXP. CON: Daylight or flash. Accepts ASA 400 film.
 FLASH: Automatic electronic. Recycles in 2 seconds.
 CONSTRUCTION: Black plastic and metal. Measures 6.75x2.25x1.25 inches.
 ACCESS: Metal wrist strap. 20-exp. Kodak color print film. 2 AA batteries, instruct. Personalizing initials.
 ORDERING INFORMATION: Warranted by Kodak. Write for free copy, see page 33.
 C3 HA 7886C—Shipping weight 1 lb. \$79.50

(9) Kodak Ektralite 10 Camera Outfit
 LENS, SHUTTER FOCUS: See Lens and Shutter Specification Chart below. left. Fixed focus.
 EXP. CON: Daylight or flash. Accepts ASA 400 film.
 FLASH: Automatic electronic. Recycles in 10 seconds.
 CONSTRUCTION: Black plastic and metal. Measures 6.6x2.4x1.1 inches.
 ACCESS: Vinyl wrist strap. 20-exp. Kodak color print film. 2 AA batteries, instruct. Personalizing initials.
 ORDERING INFORMATION: Warranted by Kodak. Write for free copy, see page 33.
 C3 HA 7885—Shipping weight 12 oz. \$36.50

(10) Kodak Tele-Ektra 1 Camera Outfit
 LENS, SHUTTER, FOCUS: See Lens and Shutter Specification Chart below. left. Normal or telephoto lens. 3-speed shutter. Fixed focus.
 EXPOSURE CONTROL: Daylight or flash. Accepts ASA 400 film. Uses flip-flash.
 CONSTRUCTION: Black plastic and metal. 6x2.25x1.4 in. Detachable handle/cover protects and steadies camera. Lens selection lever.
 ACCESS: Vinyl wrist strap. 20-exp. Kodak color print film. Flip-flash bar, instruct. Personalizing initials.
 ORDERING INFORMATION: Warranted by Kodak. Write for free copy, see page 33.
 C3 HA 7881—Shipping weight 7 oz. \$29.50

(11) Kodak Ektra I Camera Outfit
 LENS, SHUTTER, FOCUS: See Lens and Shutter Specification Chart at left. 3-speed shutter. Fixed focus.
 EXPOSURE CONTROL: Daylight or flash. Accepts ASA 400 film. Uses flip-flash.
 CONSTR: Black plastic and metal. 4.5x2.1x1 inch.
 ACCESS: Vinyl wrist strap. 20-exp. Kodak II film. Flip-flash bar, instruct. Personalizing initials.
 ORDERING INFORMATION: Warranted by Kodak. Write for free copy, see page 33.
 C3 HA 7880—Shipping weight 7 oz. \$22.50

Kodak 110 Pocket Cameras



Camera (10) has a removable cover/handle

